


# Applying the TriLok™

*Looking down at your foot*

## 1 Undersleeve



- Pull the sleeve on over foot.
- Secure both 1½" straps with grey tabs.
- Make sure the top strap is tight.


**Note:** Leave collar with Bio Skin® logo up until step 4.

## 2 FootLok Strap™




- The white FootLok Strap™ **MUST BE APPLIED** for maximum stability.
- Follow the colored instructions printed on the FootLok Strap™. Start at the narrow end, noting Right or Left foot.

## 3 Stirrup Strap (Marked with the TriLok™ logo)



- Open strap by pulling the finger loops on each end. With TriLok™ logo facing out, attach strap with logo over achilles tendon.
- Cross each strap over the top of the foot then cross both under the foot.
- Each end is pulled up snugly and attached to the sides of the ankle.
- Keep strap attached to brace after use.

## 4 Collar



- Roll collar down and secure.

**TriLok™**